

## UNITED “DARK RED BRASS” ALLOY # 332

Thank you for using UNITED’S alloys.

UNITED’S # 332 Casting Brass is a Dark Red brass designed to cast jewelry samples, models, belt buckles, art objects, etc. It finishes to a bright pink color and **easily solders with silver or low gold formulas.**

You should obtain excellent results by following a few simple instructions.

### MELTING

Melt Temperature for casting **1050° C - 1922° F**

**NOTES: Melt temperature may vary with type of unit. This alloy is designed for casting only. # 332 Brass should not be used for gold casting! # 332 Brass should not be cyanide gold plated, use acid gold plating unless nickel subplate is used. For # 332 Brass, we recommend an ultrasonic cleaning solution called BCR available from OKITE, phone # 1-800-526-4473 ext. 2411.**

### FLASK TEMPERATURE

Normal recommended temperature in the range of **580° C to 700° C / 1076° F – 1292° F** depending on size of flask, karat & type of jewelry.

### FLUXING

Boric Acid is the recommended flux. Use as little flux as possible. Do not use carbon fluxes or any fluxes designed for refining; i.e., soda ash, saltpeter, etc. Avoid flux in bottom pour automatic casting units.

### QUENCH TIME

**20 – 25 minutes.**

### INVESTMENT REMOVAL

Most standard investment removers will successfully remove the investment powder. Fluoric-based investment removers are the best for removing the silicon oxide invisible coating. Use of aggressive acids causes stress corrosion and surface damage and is therefore not recommended.

**UNITED’S Brite-Cast™ Investment Remover works effectively in removing fire scale as well as preventing stress corrosion or surface damage of the cast piece.**

### TECHNICAL ASSISTANCE

Always available... Call 1-800-999-3463 / 1-800-999-FINE  
E-mail / [doc@unitedpmr.com](mailto:doc@unitedpmr.com) Web-Site / [www.unitedpmr.com](http://www.unitedpmr.com)

---

2781 Townline Road, Alden, NY 14004, USA.  
Phone : (800) 999-3463; International Phone : +1-(716)-683-8334  
Fax : (800) 533-6657; International Fax : +1-(716)-683-5433  
E mail: [sales@unitedpmr.com](mailto:sales@unitedpmr.com); Website: [www.unitedpmr.com](http://www.unitedpmr.com)