

---

## UNITED “PREMIUM WHITE” ALLOY # 882

Thank you for using UNITED’S alloys.

UNITED’S # 882 ALLOY may be used for **14 K – 18 K white gold casting**, which produces a **Premium White finished color**. ALLOY # 882 contains small amounts of boron deoxidizer.

You should obtain excellent results by following a few simple instructions.

### MELTING

We do recommend pre-alloying all alloy and fine gold with aggressive stirring & fluxing to assure a uniform mixture.

**Step : 1** Pre- Alloying (Fine gold + alloy) Temperature **1050° - 1060° C**  
**1922° - 1940° F**

**Step : 2** Casting Temperature for 14 K – 18 K Alloyed Grain **1010° - 1020° C**  
**1850° - 1868° F**

**NOTES: Melt temperature may vary with type of unit. This alloy is designed for casting only.**

### FLASK TEMPERATURE

Normal recommended temperature in the range of **580° C to 700° C / 1076° F – 1292° F** depending on size of flask, karat & type of jewelry.

### FLUXING

Fluxing white gold is extremely important to pick-up oxides. Boric Acid is the recommended flux. Do not use carbon fluxes or any fluxes designed for refining; i.e., soda ash, saltpeter, etc. Avoid flux in bottom pour automatic casting units.

### QUENCH TIME

**Wait at least 20 minutes prior to quenching.** (Varies according to size of flask, styles, karat etc.)

### INVESTMENT REMOVAL

Most standard investment removers will successfully remove the investment powder. Fluoric-based investment removers are the best for removing the silicon oxide invisible coating. Use of aggressive acids causes stress corrosion and surface damage and is therefore not recommended.

**UNITED’S Brite-Cast™ Investment Remover works effectively in removing fire scale as well as preventing stress corrosion or surface damage of the cast piece.**

### REMELTING

We recommend a 70% fresh - 30% scrap mix. White gold alloy has about 1/3 the reusability of yellow gold alloys.

### TECHNICAL ASSISTANCE

Always available... Call 1-800-999-3463 / 1-800-999-FINE  
E-mail / [doc@unitedpmr.com](mailto:doc@unitedpmr.com) Web-Site / [www.unitedpmr.com](http://www.unitedpmr.com)

---

2781 Townline Road, Alden, NY 14004, USA.

Phone : (800) 999-3463; International Phone : +1-(716)-683-8334

Fax : (800) 533-6657; International Fax : +1-(716)-683-5433

E mail: [sales@unitedpmr.com](mailto:sales@unitedpmr.com); Website: [www.unitedpmr.com](http://www.unitedpmr.com)