
**# 907 NICKEL PREMIUM WHITE ALLOYS FOR 14 K & 18 KARAT
WHITE GOLD FOR HAND FABRICATION OF
SHEET, PLATE & WIRE MAKING**

United # 907 premium white gold alloy is a high Nickel Alloy and is suitable only for small hand fabrication jobs. Do not use this alloy for continuous casting or large scale automated wire and sheet making. The # 907 Premium White Alloys can also be used for investment casting if desired.

MELTING

The # 907 Premium White Gold Alloys and fine gold should be melted together in a clean crucible. Put the alloy in the bottom of the crucible and the fine gold on top. Initial melting temperature should be **1080° C / 1976° F**. Drop the temperature somewhat before pouring as listed below. Boric acid flux should be used to keep the metal clean during the melting process. The molten metal should be mixed well with a stirring rod before pouring to assure a good mix. A neutral or reducing cover gas is very helpful in melting white gold alloys.

**POURING TEMP
FOR INGOTS:**

14 K – **1050° C**
1922° F
18 K – **1040 C**
1904° F

POURING

Metal should be poured into a preheated, vertical graphite, or lightly lubricated iron mold. A steady even pouring motion should be used, slowing down at the end of the pour to prevent shrinkage in the top of the ingot. Use a round rod mold for wire, and a 2 piece L shaped mold for plate and sheet.

DON'T QUENCH

Remove the ingot from the mold and allow to air cool – don't quench. Nickel white gold rolling alloys will be much softer if allowed to air cool after pouring and after annealing. Soak ingot in a hot pickle solution to remove surface oxides.

FABRICATION

The metal ingot should be cleaned of all adhering oxide or fluxes before rolling. The ingot should be rolled or drawn to a 50% reduction in size before annealing. Too small of a reduction can cause ingot to crack during anneal. After annealing continue the reduction at 50% before annealing again. Clean the ingot after each anneal in hot pickle solution. Keep the rolls, dies, and metal clean to prevent defects in the finished stock.

ANNEALING

Annealing temperature **732° C / 1350° F** for **20 minutes. DO NOT QUENCH INGOT, allow ingot to air cool.** A boric acid fire coat should be applied before annealing in an open atmosphere oven to protect the metal from heavy oxidation. Clean the ingot in hot pickle solution to remove surface oxidation after annealing. Avoid over-annealing wire, plate or sheet stock as this can cause excessive grain growth creating orange peel surface or poor strength in finished goods.

REMELTING

Use a 30% scrap to 70% fresh mix on nickel white gold alloys. White gold alloys have about 1/3 the re-usability of yellow gold alloys.

**TECHNICAL
ASSISTANCE**

Always available... Call 1-800-999-3463 / 1-800-999-FINE
E-mail / doc@unitedpmr.com Web-Site / www.unitedpmr.com

2781 Townline Road, Alden, NY 14004, USA.

Phone : (800) 999-3463; International Phone : +1-(716)-683-8334

Fax : (800) 533-6657; International Fax : +1-(716)-683-5433

E mail: sales@unitedpmr.com; Website: www.unitedpmr.com